

Low NO_x burner BIC..M

Product brochure · GB 7 Edition 08.13








- Low polluting level in menox low $\rm NO_{x}$ mode at furnace temperatures from 850°C (1562°F) thanks to flameless combustion
- Safe flame control in flame mode thanks to ionization electrode or UV sensor (optional) and reliable electrical ignition
- Constant temperature in furnace thanks to high pulse frequency
- Capacity range from 35 to 360 kW (132*10³ to 1360*10³ BTU/h)
- Air preheating to 450°C (842°F)
- Length increments enable individual adjustment either to new systems or when modernizing existing systems
- Maintenance-friendly thanks to modular design
- BICW: housing available with internal insulation to reduce the surface temperature






Modular construction consisting of the burner BIC..M or BICW..M and the ceramic tube TSC

Application

Suitable for use in industrial furnaces and firing systems in the iron and steel industries in the precious, non-ferrous and light metal sector.

The burner can be used in conjunction with the ceramic tube set TSC in brick-lined or fibre-lined furnaces. No burner quarl is necessary.



The burners are ignited by the ignition electrodes and heat up the furnace in traditional flame mode. To reduce NO_x emissions, the burner can be switched to menox low NO_x mode with flameless combustion from a furnace temperature of > 850°C (1562°F).

menox low NO_x mode is only possible in conjunction with (ON/OFF) cyclical control. In order to switch to menox low NO_x mode, a special burner control unit BCU 465..MENOX with (ON/OFF) cyclical control is required. The high outlet velocity of burners BIC...M and BICW...M thereby ensures uniform temperature distribution in the furnace.






Heat treatment

Roller hearth furnace



Examples of application Staged ON/OFF control



Explanation of symbols see legend


Burners BIC...M are switched ON/OFF by the burner control unit. Burners BIC...M and BICW...M are controlled without pneumatic air/gas ratio control system. The gas supply pressure is controlled by a gas pressure regulator VAD; the required burner capacity is set using the fine-adjusting valve VMV. The air volume is set via the opening angle of the air valve. An air pressure switch upstream of the burner monitors the functioning of the air valve. In addition, air/gas ratio monitoring for the zone or the furnace is required.

As soon as the safety temperature monitor STM signals a furnace temperature of $\ge 850^{\circ}$ C (1562°F), the burner can be switched to flameless combustion (menox low NO_x mode) to significantly reduce NO_x emissions.

Switching to menox low NO_x mode eliminates the counterpressure by the flame in the ceramic tube TSC. At a constant gas supply pressure, the gas volume increases by approximately 15%. In menox low NO_x mode, the air valve moves to a smaller open position which has been adapted to the pressure ratios.

We recommend providing for hot air compensation by an increase in air pressure depending on the hot air temperature for applications with air preheating via a central recuperator.

Staged ON/OFF control with pressure compensation



Explanation of symbols see legend

The change in the pressure ratios when switching to menox low NO_x mode can be compensated for using an additional linear flow control (LFC with IC 40). With the switchover, the LFC moves to a smaller open position and thus maintains the gas flow rate, i.e. the burner capacity, constant. In menox low NO_x mode, the air valves moves to an open position which has been adapted to the pressure ratios.

Burner type code

Code	Description
BIC BICW	Burner for gas Burner for gas with internal insulation
65-140	Burner size
Μ	For menox low NO _x operation
B G D	Gas type: natural gas butane, propane, propane/butane town gas, coke oven gas
-0 -100 -200	Length of burner extension (L1) [mm]
/35- /135- /235	Position of burner head (L2) [mm]
(1)-(99)	Burner head identifier
A-F	Construction stage

Ceramic tube set TSC type code

Code	Description
TSC	Ceramic tube set
65–140	Designed for burner size
Μ	Shape: for menox
035, 075, 110, 180, 260, 360	Capacity in kW
-300	Tube length (L8) [mm]
/35–	Position of burner head (L9) [mm]
Si-1500	Ceramic tube material

Technical data

Gas supply pressure and air supply pressure each depend on the use and gas type (gas and air pressures:

Operating characteristic diagrams and flow rate curves see www.docuthek.com **Registration in the Docuthek required.**

Overall lengths: 0 to 400 mm (0 to 15.7"), 100 mm (3.94") length increments (other lengths available on request).

Gas types: natural gas; other types of gas on request.

Control type:

staged: On/Off.

Operating range in menox low NOx mode, see www.docuthek.com, Kind of document: Operating characteristic diagram. **Registration in the Docuthek required.**

Flame control: with ionization electrode (UV control as an option).

Ignition: direct spark ignition.

Burner housing:

BIC..M: cast steel,

BICW..M: ST + internal insulation. Most of the burner components are made of corrosion-resistant stainless steel.

Maximum furnace temperature: 1250°C (2282°F); higher temperatures on request.

Maximum air temperature: up to 450°C (842°F).

The flame diameter is one to two times that of the burner tube outlet.

Maintenance cycles

Twice per year, but if the media are highly contaminated, this interval should be reduced.

Legend

-	
	Safety interlocks (Limits)
ϑ	Start-up signal
	Controlled air flow
30 5	Ignition transformer
P	Purge
\mathbb{A}	Flame signal
	Operating signal
674	Fault signal
Ж	Reset
menox	menox input
PZL	Min. pressure switch
(STW)	Safety temperature monitor
BZA	B = flame control Z = binary control function (safety-related) A = alarm, message
	Pressure regulator with solenoid valve
	Solenoid valve for gas, slow-opening
\mathbf{k}	Fine-adjusting valve
	Butterfly valve BVH with actuator IC 40



Detailed information on this product



Contact

www.kromschroeder.com \rightarrow Sales

Elster GmbH Postfach 2809 · 49018 Osnabrück Strotheweg 1 · 49504 Lotte (Büren) Germany T +49 541 1214-0 F +49 541 1214-370 info@kromschroeder.com www.kromschroeder.com

We reserve the right to make technical modifications in the interests of progress. Copyright © 2013 Elster GmbH All rights reserved.

http://docuthek.kromschroeder.com/doclib/main.php?language=1&folderid=203060&by_class=6